

Robson Industries Inc.

Replacement Filter Cartridges

Our Standard Vessel Design Utilizes Readily Available Cartridges

Stocked Nationwide by Multiple Sources including
McMaster-Carr Supply Company

McMASTER-CARR



OVER 480,000 PRODUCTS
98% of the products ordered ship from stock

With a Robson Industries Inc. Filtration System, you're not locked into our "special" cartridge size. Adapters are available to accommodate any size cartridge, or choose a custom-made vessel designed to match what you need.

**Vessels Are Available To
Match Any Cartridge Size And Configuration**

Robson Industries Inc.
510 East Barnard Street
West Chester, PA 19382

(888) 567-8308
Intl.: (610) 692-9952
Fax: (610) 692-1968

www.robsonind.com

Robson Industries Inc.
Standard Filter Cartridges

C-4015

Fulflo® Flo-Pac® Filter Cartridges

Superior Industrial Filtration From a Pleated Cartridge Design

Parker Fulflo® Flo-Pac® Cartridges are the perfect choice for many industrial filtration requirements. Flo-Pac pleated cartridges contain premium grade, phenolic impregnated cellulosic filter media. Parker's line of pleated cartridges is designed for critical filtration applications, providing long service life, high flow rate and low pressure drop.

Flo-Pac Pleated Cartridges are available in 0.5µm, 1µm, 5µm, 10µm, 20µm, 30µm, and 60µm pore sizes (95% removal; $\beta = 20$).



Benefits

- Pleated cellulosic media allow high flow capacity at low pressure drop
- Available in a variety of sizes and configurations to fit most industrial vessels
- Phenolic resin impregnated to provide strength, integrity and high contaminant capacity
- High strength spiral core withstands pressure surges to 100 psid
- Suitable for operating temperatures to 250°F (121°C)

- Outer sleeve protects the media from damage
- ETP (Electro-tin-plated) steel metal components for both aqueous and oil-based applications
- Buna-N gaskets are standard, other materials are available

Applications

- Water Soluble
- Coolants
- Quench Oils
- Fuels
- Lubricating Oils
- Hydraulic Oils
- EDM Dielectrics
- Rolling Mill Oils
- Processing Liquids
- Gasoline



ENGINEERING **YOUR** SUCCESS.